

Machine vision for closed-loop robot operation

Operating Procedure

power on	
scan for images	1) connect to WiFi or insert an empty USB drive 2) begin scanning 3) upload images
install algorithm	1) download algo.so file 2) wait for new algorithm to be installed
begin production	1) monitor output pins 2) begin scanning 3) monitor from any device
maintain	1) download NOWING maintenance file 2) wait for status indicator

			Inputs	& Outputs
Camera	Camera		Input:	5V 2A power input SNAP pin
Focus:	3.8 mm		Outpu	service port (serial) t:
Field of view:	70 degrees		-	STATUS pin
Range:	15 cm - infinity			OK pin
Distortion:	<1%			NG pin
Image scan res	solution and speed:	2592 x 1936 7 fps		HDMI
		1920 x 1080 12 fps	USB 8	WiFi enabled

